

**ERRATA SHEET FOR
ASHRAE STANDARD 111-1988**

January 9, 1997

Introduction

The correction listed in this errata sheet applies to all copies of ANSI/ASHRAE Standard 111-1988 with a blank outside back cover (i.e., no printer's symbol).

Errata

On page 64, Figure D-10, values in table column headed "Position Relative to Inner Wall," in row for 5 points or traverse lines, change the second value:

From:	0.238
To:	0.288

so that the values in the 5-point row read as:

0.074, 0.288, 0.500, 0.712, 0.926